

Authorized quality manager

Before assembly, working area should be empty and clean.

All parts and subassemblies to be picked before the assembly order starts.

Assembly only by qualified personnel. Tractive tooling and qualified machines should be in good order.

Only components supplied/released by Tractive, may be assembled.

All loctite joints to be clean before Loctite application.

Follow part and setting list. In case of conflict with work instructions, please follow the part and setting list.

Pistonrod cpl.

Put the ball d3.5 46000169 and the checkvalve spring part no 46000092 in the needle seat d3 part no 46000089. Lock the spring with the checkvalve bleed nut part no 46000094 using an allen key 3mm. Torque 3Nm and Loctite 2701.

Srew the needle seat into to pistonrod. Torque 3Nm without loctite. Deform the pistonrod on the top with a hamer. Do not damage the outer thread.










Revision 1 Rev. date 27-9-2011


Authorized quality manager

Piston rod cpl.

Put the needle subassey into the pistonrod. Check if the needle sticks out approx 3mm. measured from the point to the pistonrod surface If it's less then 2mm or more the 4mm there is a mistake in the parts combination needle /pistonrod.



Mount the springretainer cup part no 46000040.






Revision 1 Rev. date 27-9-2011

Authorized quality manager

Put on the bumprubber and the cover part no 46000049 over the piston rod



Put tool part no 90100039 over the pistonrod tap and mount the holder part no 46000050S1/2/3






Revision 1 Rev. date 27-9-2011

Authorized quality manager

Remove the tool and mount the rebounddisk, compression shimstack, piston, rebound shimstack, pistonrod nut part no 46000106.

Torque: 30 Nm without loctite Mount O-ring 37.82x1.78 part no 46000087. No grease.



Mount the 2 O-rings 49x2 part no 46000095 around the tube body. For visible purpose in this picture red.

After mounting grease them with PP300.






Revision 1 Rev. date 27-9-2011


Authorized quality manager

Mount springring part no 46000084.

Press in the bearing part no 46000044 with tool part no 90200013

Mount the second springring.









Revision 1 Rev. date 27-9-2011


Authorized quality manager

Mount the springring part no 46000097 in the groove with the opening located on the position needed for the locking bolt part no 46000120

Torque: 3 Nm Loctite 2701



Place the shock tube in clamping block part no 90100040 (See picture). Use tool part no 90100005S to tighten the contra nut. Torque: 75 Nm



Tractive Suspension BV, Kerkstraat 14, 5439ND Linden, the Netherlands, info@tractivesuspension.com, www.tractivesuspension.com


p. 6



Revision 1 Rev. date 27-9-2011

Authorized quality manager

Bearing bushes: Press in the



Mount the 2 O-rings 18x1.5 (red color on picture) with part no 46000101

required bearing bushes together with the seal.

The seal can be an O-ring 18x3 part no 46000148 or a yellow seal part no 46000085

Mount the low speed adjuster (left) and the high speed adjuster (right) with tool part no 90100002.

Torque: 12 Nm






Revision 1 Rev. date 27-9-2011

Authorized quality manager

Mount the springretainer screw M53x1.5 part no 46000042. Place the spacer part no 46000107 on top of the springretainer.

Mount the protection sleeve part over the tube.





Mount the piston rod assey in the tube

Put piston ring part no 46000088 over the piston.

Srew the holder into the tube with tool no 90100004S.






Revision 1 Rev. date 27-9-2011

Authorized quality manager

Screw the cover part no 46000049 into the holder and tighten it with tool part no 90200032S



Tooling picture needs updating